



WOLFvision®

1. Connect your screen via HDMI



HDMI

2. Connect your network


For an optional corporate network integration



3. Plug device into power outlet




4. Ready to go



Connect & Share


Wireless HDMI on Windows 8.1+

1. Press  + K to list local **Wireless Display** receivers.
2. Select your Cynap Pure.
3. **Activate User Input Back Channel** on a Windows PC/laptop to allow touch back control of it via Cynap Pure connected touch screen.

Wireless HDMI on Android

1. Open **Quick Settings**.
 2. Select Miracast, ***Screen Mirroring**
 3. Select your Cynap Pure
- *aka Cast, Smart View, AllShare**


Apple AirPlay on MacBook, iMac

1. Connect to Cynap Pure using the listed Wi-Fi settings.
2. Click  in the menu bar at the top of your screen.
3. Choose your Cynap Pure.

Apple AirPlay on iPhone / iPad

1. Connect to Cynap Pure using your camera to scan the **QR code**.
2. Swipe down to open **Control Center** and tap on **Screen Mirroring**.
3. Tap on your Cynap Pure or swipe down if the list contains more than 3 entries.

Chromecast on Chrome browser

1. Connect to Cynap Pure using the listed Wi-Fi settings.
2. Open Chrome browser and click on browser menu  then click on **Cast...**
3. On Cast menu decide to cast desktop or browser window and select your Cynap Pure.


Chromecast on Android

1. Connect to Cynap Pure using your **camera** to scan the **QR code**.
2. Swipe down to open **Control Center** and tap on **Screen Mirroring**.
3. Tap on your Cynap Pure or swipe down if the list contains more than 3 entries.

Connect and control

Enter Cynap Pure IP address
in your browser.

Click on  to open toolbar.



Cynap Pure Configuration

Click on cogwheel  and use initial default admin password: **Password**

GENERAL



✓Solution

CYNAP



ADMIN

Password



CANCEL


LOGIN

Cynap Pure
Setup

Network Integration Guide

...carried from an existing virtual server. Cynap Pure generates an independent WLAN, and LAN enabled (BYOD) can connect to Cynap Pure.

...through the Cynap Pure can be accessed from an existing virtual server. Cynap Pure and also the Guest network can be connected to Cynap Pure.



Available on
our website.



Advantages:

- All devices can communicate with each other
- Cynap Pure has access to the internet
- Cynap Pure can access additional devices
- Security issues - BYOD


Advantages:

- All devices can communicate with each other
- Cynap Pure has access to the internet
- Cynap Pure can access additional devices

<http://bit.ly/2VqVDm3>

Cynap Pure
Setup

Help!



<http://bit.ly/2PwwPoK>

Cynap Pure
Setup

THE POWER OF FOUR



CYNAP Mediahub



PURE Mirroring



CORE Collaboration



CYNAP PURE PRO

vSolution

CYNAP