

## Additional Information

Due to currently improving the usability of the Visualizer, the following functions are changed:

### View Mode

The VIEW key works as toggle key and switches from live view to internal memory, to USB-stick (if available) and back to live image.

### Erasing pictures from memory

Stored pictures can be erased in the on-screen menu of the View Mode.

### On-screen Menu

The function „Format Protect“ is changed to respective submenus and deleted respectively. In the menu Advanced Settings / OSD Settings the language of the on-screen menu and on-screen messages can be changed.

Changes are effective with firmware version v1.21b.

## Zusatz Information

Durch ständige Verbesserung der Bedienbarkeit des Visualizers wurden folgende Funktionen geändert:

### View Modus

Durch Drücken der VIEW Taste wechselt der Visualizer vom Live Bild zum internen Bildspeicher, durch erneutes Drücken zum USB-Stick (wenn verfügbar). Nochmaliges Drücken schaltet wieder in den Live Modus.

### Löschen von gespeicherten Bildern

Gespeicherte Bilder können im On-Screen Menü des View Modus gelöscht werden.

### On-screen Menü

Die Funktion „Format Protect“ wurde in entsprechende Untermenüs geändert beziehungsweise gelöscht.

Im On-Screen Menü unter Erweiterte Einstellungen / OSD kann die Sprache des On-Screen Menüs und der Bildschirmmeldungen geändert werden.

Änderungen sind wirksam ab der Firmware Version v1.21b.